



Blimp Inflator

Instruction Sheet

Inflator Hook-Up



Firmly hand tighten inflator to the cylinder valve by turning the handwheel clockwise. Do not use a wrench.

Filling



1. Insert Filling Hose into the neck of the balloon or giant inflatable.
2. Firmly grasp balloon or giant inflatable around the Filling Hose with one hand.
3. Slowly open the cylinder valve to begin inflating. **CAUTION:** Always grasp the Filling Hose tightly when the cylinder valve is open to prevent hose from whipping around and causing injury.
4. When balloon or giant inflatable is fully inflated, close cylinder valve.
5. Follow balloon or giant inflatable instructions to tie off.



Inflator Removal



Unscrew hand-tight connection and remove inflator.